



6759 Baymeadow Drive  
Glen Burnie, MD 21060  
410.768.1933  
Hello@TENTING.com

## HYGIENE BARRIER CLEANING

What you will need:

- x2 Microfiber cloth or 100% cotton cloth
- Water (preferably distilled)
- Dish soap

Step 1. Start by gently dusting the surface removing large debris to prevent scratching. Step 2. Mix the water with soap, and soak one of the cloths with the solution.

Step 3. Gently wipe the acrylic surface with the wet cloth.

Step 4. Once the surface has been cleaned up, gently use the dry cloth to dry surface.

**Avoid ammonia-based products,  
like Windex or other glass cleaners as they will damage  
the surface leaving it cloudy looking.**

## Removing clear mounting tape

What you will need:

- WD-40©
- Goo Gone©
- Plastic scraper (ex. credit card)
- Cloth (optional)

Step 1. Apply enough WD-40 to the tape to saturate. Let sit for 5 minutes.

Step 2. Use plastic card, starting at a corner to peel up tape. In a sawing motion scrape card under the tape until the bulk of the tape is removed.

Step 3. Saturate the remaining adhesive area with Goo Gone©

Step 4. Scrape surface again with card, or scrub with cloth until adhesive is removed.